



Gelenkkurbelöse für RolloTube Basis mit Handkurbelfunktion (HK)

Kurzanleitung zur Montage



GEFAHR!



Lebensgefahr durch Stromschlag bei Berührung von elektrischen Komponenten.

Trennen Sie die Zuleitung allpolig vom Netz und sichern Sie sie gegen Wiedereinschalten, bevor Sie die Gelenkkurbelöse montieren.



VORSICHT!



Bei geöffnetem Rollladenkasten besteht Verletzungsgefahr durch Quetschen der Hand.

Greifen Sie nie bei laufendem Motor in den Bereich der Wickelwelle.



1

Als erstes den Rohrmotor im Rollladenkasten unter Beachtung der Rohrmotoranleitung montieren.



2

Anschließend das Loch zum Durchstecken der Kurbelgelenkstange bohren.



3

Die Kurbelgelenkstange durch die Wand in das Nothandgetriebe des Motors stecken.



4

Die Gelenkplatte am Mauerwerk befestigen.



5

Bei Stromausfall die Handkurbel einhängen und den Rollladen per Hand öffnen oder schließen.

- ◆ Die Handkurbel darf nur bei Stromausfall bedient werden. Außerdem ist darauf zu achten, dass die Endlagen nicht überfahren werden dürfen.
- ◆ Die Handkurbel ist wegen Verletzungsgefahr oder Sachbeschädigung sofort nach Betätigung wieder aus der Anlage zu entnehmen.



Articulated hand crank eyelet for RolloTube Basic with hand crank function (HK)

Brief instructions for the installation



DANGER!



Risk of fatal electric shock when touching electrical components.

Disconnect all phases of the mains power lead and secure it to prevent any reconnection before you install the articulated hand crank eyelet.



CAUTION!



Risk of crushing injuries to the hand when working with the roller shutter box open.

Never reach into the area of the winding shaft when the motor is running.




First, install the tubular motor in the roller shutter box in accordance with the tubular motor instructions.




Then drill the hole to insert the articulated crank rod.



Push the articulated crank rod through the wall into the emergency motor drive.



Fix the articulated plate to the masonry.



Attach the hand crank in the event of a power failure and open or close the roller shutter manually.

- ◆ The hand crank must only be used in the event of a power failure. Also make sure that the end positions are not overrun.
- ◆ The hand crank must be removed from the system again immediately after using it due to the risk of injury or property damage.